

Setting up the Adobe PostScript driver for Windows 3.1

NOTE



The files for this driver are available on the printer's CD-ROM and on the AdobePS 3 Driver diskette.

If you already have the driver installed and you are only adding the Phaser 350 printer, open the Control Panel, double-click the Adobe driver icon, then continue with [Step 5](#).

If you already have the driver installed and you want to add a printer other than the Phaser 350 printer, open the Control Panel, double-click the Adobe driver icon, then continue with [Step 5](#). Printer PPD files are located in the \WIN95_NT directory on the printer's CD-ROM only.

- 1** Insert the printer's CD-ROM into your CD-ROM drive, or insert the AdobePS 3 Driver diskette into your disk drive.
- 2** In the **Program Manager** in Windows 3.1, select **Run** from the **File** menu.
- 3** At the **Command Line**, do one of the following:

- **CD-ROM:** Type in the drive the CD-ROM is in, followed by the `\ADOBEPS3` directory and the file name *SETUP.EXE*, and click **OK**. For example:

C:\ADOBEPS3\SETUP

- **Diskette:** Type in the drive the diskette is in, followed by the file name *SETUP.EXE*, and click **OK**. For example:

A:SETUP

- 4 When the **README.WRI** dialog box appears, select one of the buttons as desired.
- 5 In the **PostScript Printer Driver Setup** dialog box, click **Continue** to begin the driver installation. This installer overwrites older versions of the Adobe PostScript driver.
- 6 A message appears as files are copied to your hard disk. Click the **Restart Windows** button when the installation is complete.

- 7 When the **Install PostScript Printer from PPD** dialog box appears, select your printer in the **Printer Descriptions Available** list and click **Install**:
 - Select **Tektronix Phaser 350** if you have the standard version of the printer.
 - Select **Tektronix Phaser 350 600x300** if you have the printer's Extended Features option.

N O T E



If you are not sure which configuration of the printer you have, the printer's startup page lists this information under **Extended Features: Yes/No**.

- 8 At the installation successful message, click **OK**.
- 9 Click **Close** in the **Install PostScript Printer from PPD** dialog box.
- 10 At the message, click **OK**; the **Control Panel** opens.
- 11 From the **Control Panel**, double-click **Printers**.

- 12** In the **Printers** dialog box, select the **Tektronix Phaser 350** printer you just installed, then click **Connect**.
- 13** In the **Connect** dialog box, select the port the printer is connected to, then click **OK**.

N O T E



Refer to the Adobe PostScript Printer Driver User Guide on the printer's CD-ROM (USRGUIDE.PDF) for more detailed information on the AdobePS 3 driver.