
## **Downloading files from Windows**

You can use the **Copy** command in the Windows **File Manager** to download PostScript files to the printer.

- Locate the files you want to use on the Tektronix Windows 3.1
  Driver and Printer Utilities diskette. You can copy the files to
  your computer's hard disk, or use the files directly from the
  diskette.
- In Windows, double-click the File Manager icon in the Main window.
- 3. Locate the drive and directory or subdirectory containing the printer's utility files.
- Select the utility file you want to send to the printer, for example RESET.PS.
- 5. Select **Copy** from the **File** menu. The **Copy** dialog box appears with the selected utility file displayed in the **From** field.



- In the To field, type the port your printer is connected to. For example, type LPT1: for a parallel port connection. Click OK.
- 7. If the **Confirm File Replace** dialog box appears, click the **Yes** button to continue. The file is downloaded to the printer.

Source: 070-9009-00 C3