

# PHASER® 6200 COLOR PRINTER

## Paper Tips

The Multi-Purpose Tray (MPT) and other trays use only certain sizes and types of paper or transparencies. Follow these tables to ensure the best print quality and to avoid paper jams. For best results, use only **Xerox Phaser®** branded media as it is guaranteed to produce excellent results on your Phaser® 6200 Printer - the Phaser® 6200 and Phaser® media are *Made for Each Other.®*

**⚠ Caution:** Damage caused by using unsupported media is not covered by your printer's warranty.

Paper Type	Tray	Letter (8.5 x 11 in.)	Legal (8.5 x 14 in.)	Executive (7.25 x 10.5 in.)	Statement (5.5 x 8.5 in.)	US Folio (8.5 x 13 in.)	A4 (210 x 297 mm)	A5 (148 x 210 mm)	A6 (105 x 148 mm)	B5 JIS (182 x 257 mm)	ISO B5 (176 x 230 mm)	Custom
<b>Plain Paper</b> 64 - 90 g/m <sup>2</sup> (17 - 24 lb Bond)	MPT	●	●	●	●	●	●	●	●	●	●	●
	Trays 1 - 3	●	●	●	●	●	●	●	●	●	●	●
<b>Heavy Plain Paper</b> 85 - 105 g/m <sup>2</sup> (22 - 28 lb Bond)	MPT	●	●	●	●	●	●	●	●	●	●	●
	Trays 1 - 3	●	●	●	●	●	●	●	●	●	●	●
<b>Transparency</b> <b>⚠ Caution:</b> Use only Phaser® 6200 Premium Transparency Film. Other transparencies may damage the printer's fuser.	MPT	●				●						
	Tray 1	●				●						
<b>Thin Card Stock</b> 100 - 163 g/m <sup>2</sup> (26 - 60 lb Cover)	MPT	●	●	●	●	●	●	●	●	●	●	●
<b>Thick Card Stock</b> 160 - 216 g/m <sup>2</sup> (59 - 80 lb Cover)	MPT	●	●	●	●	●	●	●	●	●	●	●
<b>Envelope</b> You can also use custom envelope sizes. <b>⚠ Caution:</b> Use only paper envelopes. Do not use envelopes with windows or metal clasps.	MPT	#10 Commercial Envelope (4.12 x 9.5 in.) Monarch Envelope (3.87 x 7.5 in.) A7 Envelope (5.25 x 7.25 in.) Custom					DL Envelope (110 x 220 mm) C5 Envelope (162 x 229 mm) C6 Envelope (114 x 162 mm) B5 Envelope (176 x 250 mm)					
<b>Labels</b> <b>⚠ Caution:</b> Do not print on label stock once labels have been removed.	MPT	●				●						●
<b>Letterhead</b> 85 - 105 g/m <sup>2</sup> (22 - 28 lb Bond)	MPT	●	●	●	●	●	●	●	●	●	●	●
	Trays 1 - 3	●	●	●	●	●	●	●	●	●	●	●
<b>Glossy Coated Paper</b> 120 - 163 g/m <sup>2</sup> (81 - 110 lb Book) <b>⚠ Caution:</b> Do not use glossy ink-jet paper or non-laser glossy paper as they may cause damage to the printer's fuser.	MPT	●	●	●	●	●	●	●	●	●	●	●
<b>Business Cards</b> <b>⚠ Caution:</b> Do not print business card media once cards have been removed.	MPT	●				●						●
<b>Greeting Cards</b>	MPT	●				●						●
<b>CD/DVD Labels and CD/DVD Inserts</b> <b>⚠ Caution:</b> Do not print label or insert media once labels or inserts have been removed.	MPT	●				●						●
<b>Photo Paper</b> 120 - 163 g/m <sup>2</sup> (81 - 110 lb)	MPT	●				●						●

**Note:** Auto duplexing is only supported from Trays 1 - 3, on 75 - 105 g/m<sup>2</sup> (20 - 28 lb Bond) media. This option is not available on the Phaser 6200B and Phaser 6200N.