

Updating the Microsoft Windows PostScript driver

If you prefer to use the standard Microsoft Windows PostScript printer driver instead of the Tektronix Windows driver, follow these instructions. This update procedure provides printer page size information for Windows applications using the standard Microsoft driver. However, color corrections and other PostScript Level 2 features are available only with the Tektronix Windows 3.1 driver and are not supported by the standard Microsoft driver.

These instructions assume a basic familiarity with Windows operation and terminology. For additional information about Windows, refer to your Microsoft Windows documentation.

1. Start Windows.
2. Open the **Control Panel**.
3. Double-click on the **Printers** icon.
4. Choose the **Add>>** button; a list of printers is displayed.
5. Select **Install Unlisted or Updated Printer**.
6. Choose the **Install** button.
7. When prompted, insert the Tektronix Windows 3.1 Driver and Printer Utilities diskette into your computer's disk drive.

8. Type in the disk drive location of the diskette, and type in the \WPD subdirectory on the diskette:

B:\WPD

Then choose **OK**.

9. Choose your printer from the list, then choose the **OK** button. Select a printer name *without* the (*TekColor*) designation.
10. When asked to insert a diskette with the updated *PSCRIPT.DRV* file, enter the path for your *Windows\System* subdirectory, or insert the appropriate Microsoft Windows diskette, so the current *PSCRIPT.DRV* file is used. (The *PSCRIPT.DRV* file is *not* included on the Tektronix diskettes.)