

Installing the Tektronix driver on a network

Note *For more information on the following procedure, request a document catalog from HAL or EuroHAL, the Tektronix automated fax systems.*

System administrators may want to perform this procedure if several users are sharing the printer.

- The administrator installs the driver only once.
 - Individual users do not need to use the diskettes to install the driver.
 - Users who want to use the driver can select it from their list of installed printers through the Control Panel.
1. Install the Tektronix Windows driver.
 2. Edit the *CONTROL.INF* file as follows to make the driver available to other users:
 - a. Start **Notepad**, or a similar text editor.
 - b. Insert the Tektronix Windows 3.1 Driver and Printer Utilities diskette into your computer's disk drive, for example drive **B**.
 - c. In **Notepad**, open the *CONTROL.ADD* file on the Tektronix diskette.
 - d. Locate the Tektronix Phaser printer entries. Select your printer (highlight the line with your printer), and copy the line to the **Clipboard** by selecting **Copy** from the **Edit** menu. If desired, you can select and copy all of the Tektronix printers listed.
 - e. In **Notepad**, open the *CONTROL.INF* file located in the network Windows System directory, by selecting **Open** from the **File** menu.

- f. Search for the string *Phaser* to find the existing Tektronix printer entries.
 - g. Paste the printer information from the **Clipboard** into the *CONTROL.INF* file above the existing Tektronix printer entries, by selecting **Paste** from the **Edit** menu.
 - h. If desired, the existing Tektronix printer entries can be deleted or commented-out by placing a semicolon (;) at the beginning of each line. It might be less confusing to users to have only one Tektronix printer to choose from in the driver.
3. Windows users can add the Tektronix printer to their Printers Control Panel with the **Add>>** button.