

PANTONE Color library files for Aldus applications

Note *For the latest information on color libraries, call Tektronix Customer Support in the U.S. and Canada at 1-800-835-6100. Outside the U.S. and Canada, contact your local Tektronix reseller.*

The *PANTONE-Tek Phaser 340.clib* and *PANTONE-Tek Phaser 340.acf* files are compressed into the *Phaser 340 Apps.sea* archive file on the Macintosh Driver and Printer Utilities diskette, and must be decompressed before you can use them. Decompress these files, then continue with the steps listed below for the application version you are using.

FreeHand 3.0 and 3.1

The *PANTONE-Tek Phaser 340.clib* file is used by the application to properly specify PANTONE Colors for Aldus FreeHand and Phaser 340 printers.

- For FreeHand 3.0, refer to the *Aldus FreeHand User Manual Version 3.0 for Apple Macintosh computers* for more information on color libraries.
 - For FreeHand 3.1, refer to the *Aldus FreeHand Guide to Installation, System 7.0 Compatibility, and Feature Updates: Version 3.1 for Apple Macintosh computers* for more information on color libraries.
1. Locate the *PANTONE-Tek Phaser 340.clib* file in the folder on your hard disk containing decompressed utility files. Place the file in a convenient location.
 2. Start FreeHand.
 3. Open the **Colors** palette in FreeHand (or press **Command + 9**).

4. **For FreeHand 3.0:** Choose **Library** from the **Colors** palette submenu; a dialog box appears listing available color libraries.

For FreeHand 3.1: Choose **Import** from the **Colors** palette submenu; a dialog box appears listing available color libraries.

5. Select and open the *PANTONE-Tek Phaser 340.clb* color library file. A dialog box appears with a list of available colors.
6. Select color type, either **Process** or **Spot**.
7. Select the colors you want to use, then click **OK**. Select one color at a time, or hold down the Shift key and click to select several colors, or press **Command + A** to select all colors in the list.

Selected colors are added to the **Colors** palette, the **Colors** dialog box, and all **Colors** pop-up menus.

FreeHand 4.0

The *PANTONE-Tek Phaser 340.acf* file is used by the application to properly specify PANTONE Colors for Aldus FreeHand and Phaser 340 printers.

1. Locate the *PANTONE-Tek Phaser 340.acf* file in the folder on your hard disk containing decompressed utility files.
2. Place the *PANTONE-Tek Phaser 340.acf* file in the **Color** folder in the **Aldus** folder, inside the **System Folder**.
3. Start FreeHand.
4. From the **Colorlist** window choose **Options**, **Import** and select *PANTONE-Tek Phaser 340.acf*.

PageMaker 5.0

The *PANTONE-Tek Phaser 340.acf* file is used by the application to properly specify PANTONE Colors for Aldus PageMaker and Phaser 340 printers.

1. Locate the *PANTONE-Tek Phaser 340.acf* file in the folder on your hard disk containing decompressed utility files.
2. Place the *PANTONE-Tek Phaser 340.acf* file in the **Color** folder in the **Aldus** folder, inside the **System Folder**.
3. Start PageMaker.
4. Choose **Element, Define Colors, New, Libraries**, then select *PANTONE-Tek Phaser 340.acf*.