

# Printing from an application

Printer description files are located in the *APPLSPEC* directory on the Windows 3.1 Driver and Printer Utilities diskette. These files are required by some applications; *refer to your application's documentation to determine if you need to use one or more of these files.*

You should always use the most current printer description file. To determine the **date** of the file you are using, do the following:

1. Select (highlight) a file and choose **Get Info** from the **File** menu. Make a note of the version date.
2. Check the Tektronix Bulletin Board Service (BBS) to see if the printer description files you have are the most recent.

A few applications and their corresponding printer description files are listed in the table below.

## Printer Description Files for the Phaser 340

Application and version number	Printer description files for the standard version of the printer	Printer description files for the optional Plus configuration of the printer
Aldus PageMaker 4.0, 4.2, 4.2A (use both PPD and PDX)	TK340171.PPD (version 3.0) TK340171.PDX	TK340691.PPD (version 3.0) TK340691.PDX
Aldus PageMaker 5.0	TK340171.PPD (version 4.x)	TK340691.PPD (version 4.x)
Aldus FreeHand 3.0 or 3.1 (use both PPD and PDX)	TK340171.PPD (version 3.0) TK340171.PDX	TK340691.PPD (version 3.0) TK340691.PDX
Aldus FreeHand 4.0	TK340171.PPD (version 4.x)	TK340691.PPD (version 4.x)
QuarkXPress 3.3 (requires Windows 3.1)	TKPH3401.PDF <sup>1</sup>	TKPH3401.PDF <sup>1</sup>

<sup>1</sup> One PDF file is provided for use with either the standard version or the optional Plus configuration of the printer.