

Printer description file for QuarkXPress

The *Phaser 340.PDF* is a PostScript Printer Description file for QuarkXPress 3.11, 3.2, and 3.3. QuarkXPress lets you install support for additional printers beyond those shipped with the application. This file adds the Phaser 340 printer to the QuarkXPress list of supported printers.

The *Phaser 340.PDF* file is compressed into the *Phaser 340 Apps.sea* archive file on the Macintosh Driver and Printer Utilities diskette, and must be decompressed before you can use it. Decompress this file, then continue with the steps listed below for the application version you are using.

Note *For hints and tips on printing from QuarkXPress, request a document catalog from HAL or EuroHAL, the Tektronix automated fax systems.*

QuarkXPress 3.11 and 3.2

1. Locate the *Phaser 340.PDF* file in the folder on your hard disk containing decompressed utility files.
2. Place the *Phaser 340.PDF* file in the same folder as the QuarkXPress application on your computer's hard disk.
3. The printer's name appears alphabetically in the list of installed printers in the QuarkXPress custom **Page Setup** dialog box.

QuarkXPress 3.3

1. Locate the *Phaser 340.PDF* file in the folder on your hard disk containing decompressed utility files.
2. Place the *Phaser 340.PDF* file in the *PDF* folder inside the QuarkXPress 3.3 application folder on your computer's hard disk.
3. The printer's name appears alphabetically in the list of installed printers in the QuarkXPress custom **Page Setup** dialog box.