

Downloading files to the printer

In addition to using the printer's front panel or the options in a supported driver, the utility files offer another method for changing the way the printer operates. In some cases, a selection can only be made with a utility file. To use the files, send or download them to the printer with the *LaserWriter Utility* described below. If you are using QuickDraw GX and System Software 7.5, you can also download printer utilities from the Tektronix Phaser 340 GX printer driver.

Click on the following topics for more information:

- [Using the LaserWriter Utility to download files](#)
- [Using the LaserWriter Utility to perform other tasks](#)

Using the LaserWriter Utility to download files

The *LaserWriter Utility* is an Apple utility program you use on the Macintosh to send PostScript files and fonts to the printer.

The *LaserWriter Utility* version 7.7 is compatible with Apple System Software versions 7.x. If you are using System Software 6.x, check with the Tektronix BBS for another version of the *LaserWriter Utility* in the *LW_UTIL.SEA* compressed archive file.



LaserWriter Utility

Note *The **LaserWriter Utility** cannot be used if the printer is connected to a print server. See your system administrator to temporarily remove the printer from the print server to download necessary files.*

1. Install a supported printer driver.
2. Install the necessary files from either the Phaser 340 CD-ROM or the Printer Software for Macintosh diskette.
3. Select the appropriate printer in the **Chooser**.
4. Locate the *LaserWriter Utility* in the *PhaserTools* folder on your hard disk, and double-click its icon to start the application.
5. Select **Download PostScript File** from the **Utilities** menu.
6. Select the file you want sent to the printer, and click **Open**. (The printer's utility files were installed in the *Phaser 340 Utilities* folder inside the *PhaserTools* folder.)

7. At the prompt `Save PostScript output as:` you are asked for a file name for saving printer output. Use the default name given in the edit box or type in a new name. (Printer output includes status messages generated by the printer reporting such conditions as out of paper.)
8. Click **Save** to send the file to the printer.
9. If no output is returned by the printer, the *LaserWriter Utility* displays a dialog box; click **OK** in the box to continue. If output is returned by the printer, you won't see this dialog box; check your hard disk for the file the utility created for the printer's output.

Using the *LaserWriter Utility* to perform other tasks

In addition to downloading PostScript files and fonts, you can use the *LaserWriter Utility* to perform the following specialized tasks:

Task
Enabling or disabling the printer's startup page
Changing the printer's name
Initializing a formatted SCSI hard disk connected to the printer