Setting up a Windows NT PostScript driver

N O T E

You may need your original Windows NT setup diskettes (or CD-ROM) to complete this procedure if you need to install a PostScript printer in Step 3.

1 If your computer has an Intel-compatible processor, such as the Intel I386, go on to Step 2.

If your computer is a MIPS, Alpha, or PowerPC, you need to edit the *PRINTER.INF* file on the Phaser 350 printer's CD-ROM or Printer Software for Windows diskette.

a The Phaser 350 printer's CD-ROM and Printer Software for Windows diskette are read-only (write-protected). To edit the *PRINTER.INF* file, copy the following files from the *WIN95_NT* directory on the printer's CD-ROM, or from the top level of the diskette, to a new, formatted floppy diskette. *Place all of these files at the top (root) level of the new diskette.*

TEK1
PRINTER.INF
TK350171.PPD (for the standard version of the printer)
TK350691.PPD (for the printer's Extended Features option)

N O T E

If you are installing a Tektronix printer other than a Phaser 350 printer, copy the PRINTER.INF and printer PPD files from the WIN95_NT directory on the printer's CD-ROM.

b Open the copy of the *PRINTER.INF* file on the new diskette in a text editor such as **Notepad**.

c Locate the following section in the *PRINTER.INF* file:
```
[ProductType]
STF_PLATFORM = I386
```

d Replace the **I386** with one of the following depending on your computer type:

- **MIPS** (for a MIPS platform)

- **Alpha** (for an Alpha platform)

- **ppc** (for a PowerPC)

e Save the *PRINTER.INF* file, and go on to .

2   From the **Main** window, double-click on the **Print Manager** icon.

3   If you have a PostScript printer driver installed, go on to Step 4.

N O T E

If you do not have a PostScript printer driver installed, install one now. You need a PostScript printer driver installed because the driver files are required to complete the Tektronix printer installation.

    a   From the **Printer** menu, select **Create Printer**; the **Create Printer** dialog box appears.

    b   Under **Driver**, scroll through the list and select a PostScript printer, such as the Apple LaserWriter NT, and click **OK**.

    c   Follow the on-line instructions to install the driver files from your Windows NT CD-ROM or diskettes.

4   Install the Tektronix Phaser 350 printer. From the **Printer** menu, select **Create Printer**; the **Create Printer** dialog box appears.

5   Under **Driver**, scroll to the end of the list and select **Other**; the **Install Driver** dialog box appears.

6   When prompted, do one of the following.

■   **If you are using the Phaser 350 CD-ROM:** Type in the CD-ROM drive location, and the *WIN95_NT* directory. Click **OK**; the **Select Driver** dialog box appears.

■   **If you are using the Tektronix Printer Software for Windows diskette:** Type in the disk drive location of the diskette, and the *WIN95_NT* directory. Click **OK**; the **Select Driver** dialog box appears.

■   **If you are using an edited copy of the *PRINTER.INF* file from Step 2:** Type in the disk drive location of the diskette. Click **OK**; the **Select Driver** dialog box appears.

7 Under **Printer Driver**, choose your Phaser 350 printer from the list, then click **OK**.

- Select **Tektronix Phaser 350** if you have the standard version of the printer.

- Select **Tektronix Phaser 350 600x300** if you have the printer's Extended Features option.

N O T E

If you are not sure which configuration of the printer you have, the printer's startup page lists this information under **Extended Features: Yes/No**.

8 In the **Windows NT Setup** dialog box, type in the same path you used in Step 7 (for example, *B:*).   Click **Continue**; the **Noncritical Error** dialog box appears.

9 When you are prompted for the location of the *PSCRPTUI.DLL* file and the *PSCRIPT.DLL* file, click **Ignore**. (These files were installed in the procedure in Step 4 or were already installed.)

10 When the **Create Printer** dialog box appears, fill in the other fields as desired, then click **OK**; the **PostScript Printer Setup** dialog box appears.

11 Select options in the **PostScript Printer Setup** dialog box. Enabling the **Use Printer Halftoning** option is recommended. Then click **OK**; the **Windows NT Setup** dialog box appears.

12 If you installed a PostScript printer in Step 4, follow this procedure to delete it. (Now that the Tektronix printer is installed, this printer is no longer needed.)

   a Select the printer you want to remove.

   b From the **Printer** menu, select **Remove Printer.**

   c At the prompt, click **OK** to remove the selected printer.

N O T E

Use the following page sizes with the Phaser 350 printer:
Letter and A4.