

Installing ATM software

N O T E



ATM software is available only on the CD-ROM for the printer's Extended Features option.

- 1** Insert the printer's CD-ROM into your CD-ROM drive.
- 2** Click the **Start** icon in the taskbar on your screen. In the menu that appears, click **Run**.
- 3** In the **Run** window, type in the drive the CD-ROM is in, followed by the *IATM* directory and the file name *INSTALL1.EXE* and click **OK**. For example:

C:\IATM\INSTALL
- 4** Follow the on-screen instructions to install ATM. For more information, refer to the ATM quick reference cards that were shipped with your printer.

Source: 070-9682-00