Turning off all color corrections

If you do not want to use any TekColor color corrections, you can specify no corrections from a supported driver, or with utility files, or from the printer's front panel. Select **None** when you are doing the following:

■   Using applications that do their own color adjusting

■   Using ColorSync on a Macintosh or host color correction in Windows 95

■   Printing PANTONE Colors