

Installing printer description files

PostScript printer description files (PPDs) are used by some drivers and applications for gaining information about a printer's page sizes, color corrections, and other options. To properly use the printer with one of the following applications, install the appropriate file.

- [QuarkXPress](#)
- [Aldus and Adobe](#)

QuarkXPress

The QuarkXPress application uses a unique PDF file.

- 1 Locate the *TKPH3501.PDF*:
 - On the printer's CD-ROM in the *QUARK* directory.
 - On the Printer Software for Windows diskette in the *QUARK* directory.
- 2 Copy the *TKPH3501.PDF* file to the *PDF* subdirectory of the Quark application on your hard disk. For example:

COPY TKPH3501.PDF C:\XPRESS33\PDF

Aldus and Adobe applications

Aldus and Adobe applications, such as PageMaker and FreeHand, use PostScript printer description (PPD) files. Refer to your applications' documentation for details on using PPD files.

NOTE



To add PPDs for printers other than the Phaser 350 printer, open the WIN95_NT directory on the printer's CD-ROM.

- 1 Locate the printer's *PPD* files:
 - On the printer's CD-ROM in the *WIN95_NT* directory.
 - On the Printer Software for Windows diskette at the top level.
- 2 Select a *PPD* file:
 - Use *TK350171.PPD* if you have the standard version of the printer.
 - Use *TK350691.PPD* if you have the printer's Extended Features option.

N O T E



If you are not sure which configuration of the printer you have, the printer's startup page lists this information under **Extended Features: Yes/No**.

- 3 Copy the PPD file to the directory on your hard disk where other PPD files are located. For example, the subdirectory in FreeHand's File Manager containing printer description files should be called:

ALDUS\USENGLISH\PPD4