


Locating jammed media

Paper jams can occur in these places

- 1** Inside the exit cover
- 2** Inside the front cover:
- 3** At the manual feed slot
- 4** At the standard media tray and Lower Paper Tray Assembly



Source: 070-9682-00 C6