

Setting up the Adobe PSPrinter Driver

The Adobe PSPrinter driver uses printer-specific PPDs (PostScript Printer Description files) for information on a printer's page sizes, printing options, and media type options. To use the Adobe PSPrinter driver with a Phaser 350 printer, do the following steps. If the printer is busy, it may take some time to complete this set-up procedure; you may want to do this procedure when the printer is idle. You only have to set up a printer once.

NOTE



Refer to the Adobe PostScript Printer Driver User Guide on the printer's CD-ROM for more detailed information on the Adobe PSPrinter driver.

- 1** Install the printer's software. Select **Easy Install** to automatically install all of the necessary software, or select **Adobe PSPrinter Driver** and **Printer Descriptions** in the **Custom Install** window.
- 2** Open the **Chooser**.
- 3** Select the **PSPrinter** driver icon.

- 4 Click on the **Zone** your printer is in. See your network administrator if you have questions.
- 5 Select your printer from the list.
- 6 Still in the **Chooser**, click the **Setup** button to see a list of options.
- 7 The correct PPD file should be selected automatically.

If the PPD file is not automatically selected, a dialog box opens showing the location of the PPD files you have installed in the *Printer Descriptions* folder, in the *Extensions* folder, inside your *System Folder*. Click one of the following PPDs and click **Select**:

- Use *TK350171.PPD* with the standard version of the printer.
- Use *TK350691.PPD* with the printer's Extended Features option.

N O T E



If you are not sure which configuration of the printer you have, the printer's startup page lists this information under **Extended Features: Yes/No**.

- 8 In the dialog box that appears, select the appropriate items under **Installable Options** then click **OK**.
- 9 Click the **Chooser's** close box.