

Updating the Microsoft Windows PostScript driver

If you prefer to use the standard Microsoft Windows PostScript printer driver instead of the Tektronix Windows driver, follow these instructions. This update procedure provides printer page size information for Windows applications using the standard Microsoft driver. However, color corrections and other PostScript Level 2 features are available only with the Tektronix Windows 3.1 driver and are not supported by the standard Microsoft driver.

These instructions assume a basic familiarity with Windows operation and terminology. For additional information about Windows, refer to your Microsoft Windows documentation.

1. Start Windows.
2. Open the **Control Panel**.
3. Double-click on the **Printers** icon.
4. Click the **Add>>** button; a list of printers displays.
5. Select **Install Unlisted or Updated Printer**.
6. Click the **Install** button.
7. When prompted, insert the Tektronix Windows 3.1 Driver and Printer Utilities diskette into your computer's disk drive.
8. Type in the letter for the computer's disk drive followed by the `\WPD` subdirectory:

B:\WPD

Then click OK.

9. Select your printer from the list, then click **OK**.

Note *Printers using the Tektronix Windows driver have (TekColor) listed in their name. Printers without this designation are using the standard Microsoft Windows PostScript driver and the WPD file.*

10. When asked to insert a diskette containing the updated *PSCRIPT.DRV* file, enter the path for your *WINDOWS\SYSTEM* subdirectory, or insert the appropriate Microsoft Windows diskette. This ensures that the current *PSCRIPT.DRV* file is used. (The *PSCRIPT.DRV* file is *not* included on the Tektronix diskettes.)