

Installing the Tektronix driver on a network

Note *For more information on the following procedure, request a document catalog from HAL or EuroHAL, the Tektronix automated fax systems.*

1. Install the Tektronix Windows driver.
2. Edit the *CONTROL.INF* file as follows to make the driver available to other users:
 - a. Start **Notepad**, or a similar text editor.
 - b. Insert the Tektronix Windows 3.1 Driver and Printer Utilities diskette into your computer's disk drive; for example, drive **B**.
 - c. In **Notepad**, open the *CONTROL.ADD* file on the Tektronix diskette.
 - d. Locate the Tektronix Phaser printer entries. Select your printer (highlight the line for your printer), and copy the line to the **Clipboard** by selecting **Copy** from the **Edit** menu. If desired, you can select and copy all the Tektronix printers listed.

- e. In **Notepad**, open the *CONTROL.INF* file located in the network *WINDOWS\SYSTEM* subdirectory by selecting **Open** from the **File** menu.
 - f. Search for the string *Phaser* to find the existing Tektronix printer entries.
 - g. Select **Paste** from the **Edit** menu to paste the printer information from the **Clipboard** into the *CONTROL.INF* file above the existing Tektronix printer entries.
 - h. If desired, the existing Tektronix printer entries can be deleted or commented-out by placing a semicolon (;) at the beginning of each line. It might be less confusing to users to have only one Tektronix printer to choose from in the driver.
3. Windows users can add the Tektronix printer to their Printers Control Panel using the **Add>>** button.