


# Configuration overview

The following diagram summarizes the steps of the configuration procedure.



9109-13

The default language for the LocalTalk, EtherTalk, and TokenTalk ports is PostScript. Refer to your printer's drivers and utilities manual for information about changing the printer's default language.

Source 070-9109-01 C7