

Before you begin

Before you begin the NetWare configuration, make sure that you have completed the following steps:

- Your printer should be set up and connected to the network. See your printer's user manual for information about setting up and turning on the printer.
- If you are using Windows, the Tektronix driver for your printer should be installed on every PC that will be sending print jobs to the printer. For details on driver installation, see the printer's user manual.