How to tell which protocols are enabled in your printer

All protocols can be enabled and disabled. The configuration page reports which protocols are enabled. If a protocol is enabled, the field for that protocol lists the current parameters. If the protocol is disabled, the field for that protocol contains an entry reading "Disabled."

For more information on the configuration page, see the topic "Your printer's configuration page".