


NetWare 4.1 configuration: overview

The following diagram summarizes the configuration procedures for NetWare 4.1.



Note Version 3.1 of the PhaserShare Administrator supports NetWare 4.1 with NetWare Directory Services (NDS).

Print the configuration page

Your printer's configuration page reports information that you need for NetWare configuration. For information on printing a configuration page, see the web topic "Your printer's configuration page."