

Your printer's network utilities diskettes

Note *Do not confuse the printer's network utilities diskettes with the standard printer utilities diskettes. The standard utilities diskettes contain PostScript files for printer configuration not related to networking.*

Your printer's network utilities diskettes contain programs for authorizing TCP/IP and for configuring your printer on a network. Use the appropriate diskette for your network. The PhaserShare LocalTalk/Serial card comes with a single Macintosh diskette. The PhaserShare Ethernet and Token Ring cards come with all of the diskettes listed here:

- For LocalTalk, EtherTalk, and TokenTalk networks, use the software on the Macintosh version of the printer's network utilities diskettes.
- For NetWare networks, use the software on the PC version of the printer's network utilities diskettes for installation and printer configuration. In addition, the PhaserShare diskette contains the PhaserShare Status Monitor, which allows Windows 3.1 users to monitor the status of networked printers over NetWare networks.
- For TCP/IP networks, use the software on the UNIX workstation version of the printer's network utilities diskettes. This diskette contains shell scripts that create PostScript files for TCP/IP authorization and configuration. It also contains PostScript files that you can send directly to the printer to perform various configuration tasks.

This diskette can be read by any UNIX workstation that can read **tar** format. If your UNIX workstation cannot read **tar** format, you can download the files from the Tektronix Color Printer Information Server. For instructions on downloading files, see the web topic "Downloading files from the Tektronix Color Printer Information Server."

Note *If you have a TCP/IP network without any UNIX hosts, you can use the file IPCONFIG.PS on the PC version of the network utilities diskettes to configure the printer for TCP/IP networks. You could also use the file Configure IP on the Macintosh version of the diskettes.*

The following table lists the Tektronix printer networking software according to the tasks required for network configuration. The files listed in the table are on the network utilities diskettes.

Tektronix printer networking software

Task	Macintosh file	PC file	UNIX file
Add/remove CTRL-D characters to/from PostScript files	None	ADDCTRLD.BAT CTRLD.PS	addctrlrd delctrlrd
Authorize TCP/IP protocol	Authorizer	AUTHRIZR.EXE	authorize-feature*
Change printer's name	LaserWriter Utility	PRNTNAME.PS	None
Download PostScript Error handler to printer	Tek Error Handler	TEKEHAND.PS	tekehand.ps
Enable and disable filtering of control characters from files	None	FILTER.PS NOFILTER.PS	None
Enable and disable protocol operation	Enable EtherTalk Disable EtherTalk Enable NetWare Disable NetWare Enable TCP-IP Disable TCP-IP Enable TokenTalk Disable TokenTalk	ETALKON.PS ETALKOFF.PS NWAREON.PS NWAREOFF.PS TCPIPON.PS TCPIPOFF.PS TTALKON.PS TTALKOFF.PS	ethertalk-on.ps ethertalk-off.ps netware-on.ps netware-off.ps tcp-ip-on.ps tcp-ip-off.ps tokentalk-on.ps tokentalk-off.ps
Perform NetWare configuration	None	Advanced Configuration Tool (<i>ACT.EXE; ACT.PIF</i>)	None
Print configuration page (Ethernet and LocalTalk/Serial cards)	Configuration Page	PRNTCNFG.PS	prntcnfg.ps
Print configuration page (Token Ring cards only)	Token Ring Config Page	PRTRCNFG.PS	print-token-cnfg.ps
Reset printer	Reset Printer	RESET.PS	reset.ps
Set EtherTalk zone	Set EtherTalk Zone	ETHRZONE.PS	None
Set TokenTalk zone	Set TokenTalk Zone	TOKNZONE.PS	None
Set TCP/IP device parameters	<i>Configure IP</i>	IPCONFIG.PS	config-IP* config-LPR* config-SNMP* config-sockets* config-syslog*
Set Token Ring parameters	Configure Token Ring	TOKNCNFG.PS	config-TokenRing*

* These files require that the file *job-error-handler* be installed in the same directory. The file *job-error-handler* is supplied on the UNIX diskette.